

UNDERLAY

Quality underlay costs only a small amount more but makes a big difference to a carpet installation.

It is important that Architects and Interior Designers specify the underlay to be used on all projects.

Premium quality wool carpet requires a high-quality underlay to ensure comfort and performance. A poor-quality underlay will tend to flatten especially in hallways and on stairs and make the carpet appear "tired". Occasionally builders and contractors will use cheap underlay with quality carpets to the detriment of a project.

A good underlay will spring back and ensure comfort and an abundant appearance for a longer period.

Underlays that we recommend if appropriate for the installation include:

Dunlop Springtred Ultimate

10.00mm foam 120 kg. / m³ density for high quality residential and commercial installations

Dunlop Durafit 7

7.00mm high density rubber underlay 415 kg. / m³ density for heavy contract use for Dual Bond and stretch fit installations.

Dunlop Technics 5

5.00 high density rubber underlay 542 kg. /m³ for heavy contract use

If using foam underlays or recycled fabric underlays from a reputable supplier, we recommend that you specify the top of the range products where possible.

Quality underlay costs only a small amount more but makes a big difference to a carpet installation. Please see manufacturers warranty terms and conditions.

www.supertuft.com.au
sales@supertuft.com.au

+61 03 9427 8600



SUPERTUFT